



Manufacturers of Pleasure Boats

Directors—
J. R. PRICE, C.Eng., M.I.E.E.
D. C. F. BARTLETT, B.Sc.(Eng.)
J. J. DAIN, F.C.M.A.

(Registered Office)
PARK ROAD,
DISS, NORFOLK IP22 3AY
Telephone—DISS (0379) 2280
Telex—98162
Our ref.
Your ref.

"SEAFIRE"

WINDSCREEN FITTING INSTRUCTIONS

The nylon screws and nuts provided are sufficient for attaching the windscreen to the "Seafire".

It is important to start bolting the screen from the centre and working outwards. If possible this is best carried out by one person sitting inside the boat to hold the screen bent in place whilst a second person fixes the screws from outside. For convenience of fixing it will be found that the last few holes on each side of the windscreen dais are tapped so that the screws can be fitted without the necessity of fitting on the nuts. However, care must be taken not to overtighten and strip the threads. If a thread is stripped there are sufficient nuts to allow for a nut to be put on the back. Do not tighten the two end screws until the chrome windscreen trim has been pushed into place and cut off level with the end of the windscreen on each side. Once this has been completed tighten the screws and in so doing you will help to hold the trim in place.

The trim, if preferred, (or, if at any time it gets knocked off) can be glued on.

1st NOVEMBER, 1974.

REF. 2358/1147/SO